

# PRG

Podstawa tłumiąca do dachów  
płaskich/skośnych



## wymiary

| Typ              | A<br>[mm] | B<br>[mm] | C<br>[mm] | H <sub>4</sub><br>[mm] | H <sub>5</sub><br>[mm] |
|------------------|-----------|-----------|-----------|------------------------|------------------------|
| PRG/PPG 630/560  | 880       | 770       | 996       | 950                    | 950                    |
| PRG/PPG 710/630  | 980       | 870       | 1134      | 1250                   | 1250                   |
| PRG/PPG 800/710  | 1100      | 990       | 1254      | 1300                   | 1300                   |
| PRG/PPG 900/800  | 1230      | 1120      | 1384      | 1350                   | 1350                   |
| PRG/PPG 1000/900 | 1380      | 1270      | 1534      | 1450                   | 1450                   |

\* oznaczenie PRG/PSG wymiar wentylatora / średnica pozostałych akcesoriów

